

# **PL-8800**


## **ULTRASONIC - Parking Sensor**

### **OWNER'S MANUAL**


CONTENTS:


OPERATING INSTRUCTIONS DESCRIPTION OF FUNCTIONS AND FEATURES WIRE CONNECTION GUIDE INSTALLATION GUIDE


Before operating this set, please read these instructions completely.





#### **Sensors Distance**















#### UNABLE DETECTED OBJECTS



#### **Technological Specification**

Voltage:	DC +12v
Current:	40 mA
Detect Distance:	2 – 150 cm
Detect Angle:	H > 100 deg > 50 deg
Temperature:	-20c to +65c

Should any problem persists, please contact your dealer, installer, and technician.

- Thanks for purchasing elfinx products -